



## PRODUCT APPLICATION

### General Application Requirements

All our products require are that your walls are:

- Internal walls only and dry
- Remove any dust – increases the number of times our products can be reapplied!
- Newly painted walls need 4 weeks to outgas before application.
- Remove blue-tack, hooks or fixtures that prevent a smooth finish.

### Applying simple decals

- Plan where you will put the designs, you can use blue-tack to temporarily hold them in place while you plan the final positioning (before you remove the backing paper!).
- See if the sheet includes a plan to putting it together.
- Peel the decals from the backing paper and smooth the designs to the wall.

To reposition them, just lift an edge and peel them off the wall.

Refer to the Cleaning Instructions to care for and store your wall stickers.

### Applying larger decals

Instructions to avoid the pieces sticking to themselves:

- Place the decal face down, peel back and fold 15cm of the backing paper, exposing some of the sticky side.
- Pick up the piece and stick it to the wall – support it by holding it to the wall.
- Pull the remaining backing away gradually, smoothing to the wall as you go, until all backing paper comes away and the sticker is fully applied.